Additional Language Characters & Other Symbols

A. Press and hold **Alt** key
B. Select number from list and enter via numeric pad.
C. Release **Alt** key.

If ▮ appears, verify by pressing and holding **Alt** key and entering display identifier. To restore display, press and hold **Alt** key and enter zero.

Ä=099	È=116	Õ=239	ä=067	é=081	ø=112	£=177	@=124	¦=106	»=139
À=100	É=113	Ø=128	à=068	ï=087	ß=089	¥=178	[=074	¼=183	@=175
Á=101	Ï=119	ß=089	á=069	ì=088	ü=220	ƒ=180	]=090	½=184	ª=154
Ã=102	Ì=120	Ü=252	â=070	í=085	ù=221	¤=159	±=143	¾=185	º=155
Å=103	Í=117	Ù=253	å=071	ñ=073	ú=222	¢=176	{=192	²=234	µ=160
Æ=158	Ñ=105	Ú=254	æ=156	ö=204	ÿ=223	₧=179	}=208	³=250	¯=186
Ç=104	Ö=236	Ý=173	ç=072	ò=205	ý=141	¡=170	¦=187	¶=182	¯=202
Ë=115	Ò=237	Ð=172	ë=083	ó=206	ð=140	¿=171	\=224	§=181	_=191
	Ó=238	Þ=174	è=084	õ=207	þ=142			«=138	°=144

Display Identifier: 1=USA 2=Canada 3=Europe 4=Iceland 5=Spain/Spanish Speaking

Block Graphics

A. Press and hold **Alt** key.
B. Select graphic from diagram and enter.
C. Release **Alt** key.

SX34-0051-0 Printed in U.S.A.

Programmer Commands

A. Press and hold **Cmd** key.
B. Press and release desired key.
C. Release **Cmd** key.

` PROC	1 LOAD	2 LINK	3 RUN	4 HELP STATUS	5 LIST	6 SAVE	7 REPLACE	8 MERGE	9 DIR	0 AUTO	- RENUM	= COPYD
Q CHAIN	W DATA	E DIM	R ELSE	T FOR	Y GOSUB	U GOTO	I NEXT	O OPTION	P PAUSE	[RETURN	\ THEN	
A CLOSE	S DELETE	D FORM	F INPUT	G LINPUT	H OPEN	J PRINT	K READ	L REREAD	RESTORE	" REWRITE	] WRITE	
> DISPLAY	Z FIELDS	X INTERNAL	C NAME =	V NEWPAGE	B OUTIN	N OUTPUT	M RECL =	, RELATIVE	. SIZE =	? USING		

Programmable Commands

SX34-0051-0 Printed in U.S.A.

Operator Action Codes

A. Read the blinking action code from the screen and locate it in the list to the right.
B. Follow instructions next to action code.
C. If unsure about what to do, refer to the Messages manual. If still in doubt, seek help.

10. Insert diskette.
11. Put forms in printer.
12. Give VOLID and/or drive number.
13. Fix file name or VOLID.
14. Use a different file name.
15. Fix command or procedure.
16. Use correct type of file.
17. Provide space for file.
18. Switch on printer.
19. Check file usage.
20. Check 5246 usage.
21. Switch on 5246.
22. Press Field Exit key or Enter key.
23. Enter numeric data.
24. Enter corrected data.
25. SAVE then LOAD.
26. Check write-protection.
27. Check access-protection.
28. Continue or cancel.
94. Fix program.
95. Use correct level of Customer Support Function.
96. Recover file(s).
97. Call your service representative.
98. Fix printer.
99. Look up error code.

SX34-0051-0 Printed in U.S.A.

Operator Commands

A. Press and hold **Cmd** key.
B. Press and release desired key.
C. Release **Cmd** key.

PROC	LOAD	LINK	RUN	HELP STATUS	LIST	SAVE	REPLACE	MERGE	DIR	AUTO	RENUM	COPYD
	1	2	3	4	5	6	7	8	9	0		

Additional Commands

SX34-0051-0 Printed in U.S.A.